


## Intuitive Software for Ease of Use

The simple step by step software leads you intuitively through logger configuration and information retrieval. The familiarity of the functions and structure of Console's Windows based graphical interface makes the software very easy to operate, even for new users.



Logger Overview



Multi-link




Step by step configuration process

## REDi and portal interface

You can instantly collect data from loggers located up to 4 metres away - no cables to connect and the logger simply stays put continuing its cycle without interruption. While each logger remains installed in its portal interface, the REDi reader collects the data and displays the relevant information, graph or list mode, while storing it for later download to your PC.



ESCORT REDi



ESCORT Portal

### ESCORT Console Software

Easy to use Windows based Console software for programming the logger and analysing downloaded data. The standard version is included with the PC Interface JA-INT-WIN. The extended version JA-SWP-CON has many enhanced features like Multi-Graphing and User-Administration.

### ESCORT Red-i Portable Reader & Programmer ESCORT Portal Multi Purpose Interface

Download logger data and upload new programmes to different loggers without touching your iLog. The logger resides in the battery powered Portal Interface facilitating infrared communication with REDi up to 4 meters away. REDi can take 1MB of logger data for later download to PC and is furthermore able to display downloaded data in graph or list mode for instant analysis.

### ESCORT Chartreader EJ-CR

Portable printer producing hardcopies for documentation on site: iLog simply slots into the attached interface for logger data download. If desired the logger may be re-armed for another logging cycle. Output versions are graph, list, and out of specification listing. ChartReaders are programmable using the ChartReader interface JA-CHR-INT-E for connection to PC, and the Console software. The memory version EJ-CR-MEM has 1MB memory to store multiple data sets for later transfer to PC.

### ESCORT Alarm Link JA-ALK

Interfacing device connecting to any instrument (e.g. siren, mobile phone) that will perform its function when triggered by alarm condition: Place your iLog in the alarm link interface and as soon as measurements outside the logger's specifications are recorded, the connected device is activated (e.g. audible alarm by siren, or text message sent by mobile phone).

### ESCORT PC Interface JA-INT-WIN

Convenient sit-on interface connecting to your PC via serial interface (COM port) including standard Console software. This interface and software can also be used for ESCORT Junior and Precision loggers.

### ESCORT Magnet Keyring JA-KEY

Start Magnet in form of keyring to be used for starting the logger, and for the bookmark feature.

